

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

# PRIOR TO INSTALLATION READ THESE INSTRUCTION COMPLETELY For questions, Call the FORD PERFORMANCE Techline 1-800-367-3788

Please visit <a href="https://www.performanceparts.ford.com">https://www.performanceparts.ford.com</a> for warranty information



| Kit Contents                 | Quantity |
|------------------------------|----------|
| Lamp Assembly with Aim Screw | 2        |
| Lens Cover                   | 2        |



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

#### **INSTALLATION PROCEDURE**

NOTE: Left-hand side shown, right-side similar.

1. On the left hand side turn the steering wheel all the way to the right to access the fog light assembly. See Figure 1.



FIGURE 1

2. Remove the 4 push pins securing the fog lamp assembly cover, and remove cover. Do not discard bolts. See Figure 2.




FIGURE 2



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

3. Disconnect the fog light assembly from the wire harness. See Figure 3.




FIGURE 3

4. Remove the 2 screws that secure the fog-light assembly and lamp bracket to the vehicle. Do not discard screws. Remove the fog-light assembly and bracket. See Figure 4.




FIGURE 4



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

5. Remove the 6 screws from the inboard fog light, that secures the lamp bracket with fog light assembly, to the vehicle. Do not discard screws. See Figure 5.




FIGURE 5

6. Remove the 3 pivot clamps from the inboard fog light assembly and bracket. See Figure 6.




FIGURE 6



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

7. Remove the inboard fog light. See Figure 7.




FIGURE 7

8. Install new inboard fog light into bracket.

NOTE: Reverse steps 2-6 to properly install fog light assembly and bracket into vehicle.

9. Repeat steps 1-8 for right-hand side.



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

## PRIOR TO INSTALLATION READ THESE INSTRUCTION COMPLETELY For questions, Call the FORD PERFORMANCE Techline 1-800-367-3788

Please visit <a href="https://www.performanceparts.ford.com">https://www.performanceparts.ford.com</a> for warranty information



| Kit Contents                 | Quantity |
|------------------------------|----------|
| Lamp Assembly with Aim Screw | 2        |
| Lens Cover                   | 2        |



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

#### **INSTALLATION PROCEDURE**

NOTE: Left-hand side shown, right-side similar.

1. On the left hand side turn the steering wheel all the way to the right to access the fog light assembly. See Figure 1.




FIGURE 1

2. Remove the 4 bolts securing the fog lamp assembly covers and remove covers. Do not discard bolts. See Figure 2.




FIGURE 2



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

3. Disconnect the fog light assembly from the wire harness. See Figure 3.




FIGURE 3

4. Remove the 2 screws that secure the fog-light assembly and lamp bracket to the vehicle. Do not discard screws. Remove the fog-light assembly and bracket. See Figure 4.





FIGURE 4



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

5. Remove the 6 screws from the inboard fog light, that secures the lamp bracket with fog light assembly, to the vehicle. Do not discard screws. See Figure 5.



### FIGURE 5

6. Remove the 3 pivot clamps from the inboard fog light assembly and bracket. See Figure 6.




FIGURE 6



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF FORD PERFORMANCE PARTS

7. Remove the inboard fog light. See Figure 7.




FIGURE 7

8. Install new inboard fog light into bracket.

NOTE: Reverse steps 2-6 to properly install fog light assembly and bracket into vehicle.

9. Repeat steps 1-8 for right-hand side.