




M-16601-MGG, MGM  
2024+MY Mustang GT  
Carbon Fiber GT Splitter

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF  
FORD PERFORMANCE PARTS © Ford Motor Company 2020

**PRIOR TO INSTALLATION READ THESE INSTRUCTIONS COMPLETELY**  
**For questions, Call the FORD PERFORMANCE Techline 1-800-367-3788**

Please visit <https://www.performanceparts.ford.com> for warranty information



Ford Factory Shop Manual purchase options [www.motorcraftservice.com](http://www.motorcraftservice.com)

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF  
FORD PERFORMANCE PARTS © Ford Motor Company 2020

#### BOM

Carbon Fiber GT Splitter	QTY 1
Push Pin Rivet W714040-S300	QTY 4
Screw & Washer W715060-S450B	QTY 18
Nut Clip W704823-S439	QTY 6


#### Removal

#### All vehicles

**NOTE:** Removal steps in this procedure may contain installation details.

1. Remove the front wheels and tires.
2. On both sides.  
Remove and save the bolts and the body side front shield.  
*Torque: 19 lb.in (2.2 Nm)*


E407403



Ford Factory Shop Manual purchase options [www.motorcraftservice.com](http://www.motorcraftservice.com)


NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF  
FORD PERFORMANCE PARTS © Ford Motor Company 2020

3. On both sides.  
Remove and save the push pins and position aside the front fender splash shield.



**Vehicles With: GT Performance Package**

4. On both sides.  
Remove and save the screws, push pins and position aside the front fender splash shield.  
*Torque: 19 lb.in (2.2 Nm)*




Ford Factory Shop Manual purchase options [www.motorcraftservice.com](http://www.motorcraftservice.com)


NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF  
FORD PERFORMANCE PARTS © Ford Motor Company 2020

#### All vehicles

5. Remove the bolts. New bolts are provided in the kit.  
*Torque: 19 lb.in (2.2 Nm)*




6. On both sides.  
Disconnect the side repeater lamp electrical connector.




Ford Factory Shop Manual purchase options [www.motorcraftservice.com](http://www.motorcraftservice.com)

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF  
FORD PERFORMANCE PARTS © Ford Motor Company 2020

7. Disconnect the front bumper cover electrical connector.



8. On both sides.  
Remove and save the front bumper cover to fender push-pin and the bolts.  
*Torque: 44 lb.in (5 Nm)*




Ford Factory Shop Manual purchase options [www.motorcraftservice.com](http://www.motorcraftservice.com)



NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF  
FORD PERFORMANCE PARTS © Ford Motor Company 2020


9. Remove and save the push pins and the radiator sight shield.



E407409

10. **NOTE:** This step requires the aid of another technician.

Remove and save the bolts and the front bumper cover.  
Torque: 13 lb.in (1.5 Nm)




E407557


Ford Factory Shop Manual purchase options [www.motorcraftservice.com](http://www.motorcraftservice.com)

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF  
FORD PERFORMANCE PARTS © Ford Motor Company 2020

11. Remove and save the push pins, bolts, and the underbody shield.



- 12.
1. Remove the bolts. New bolts are provided in the kit.  
*Torque: 15 lb.in (1.7 Nm)*
  2. Remove the push pins. New push pins are provided in the kit.
  3. Release the tabs and remove the front bumper splitter.



Ford Factory Shop Manual purchase options [www.motorcraftservice.com](http://www.motorcraftservice.com)



## M-16601-MGG, MGM 2024+MY Mustang GT Carbon Fiber GT Splitter

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF  
FORD PERFORMANCE PARTS © Ford Motor Company 2020

### Installation

1. Reverse the removal process.

**NOTE:** When installing the fasteners for the carbon fiber splitter, hand tighten fasteners starting from the middle and working outwards.

**NOTE:** Do not over tighten threaded fasteners, composite components will not withstand high pressure and may crack or fail by such force.

**NOTE:** Tighten fasteners fully starting from the middle and working outwards.

### Care Instructions

Carbon fiber products are durable, but still requires care and maintenance to stay looking good. More specifically, keep the products clean and minimize exposure to the sun. Gloss finish products should be waxed with a car care product designated for clear coat finishes (non-abrasive). Matte finish products should not be waxed, surface may become spotty. Grease or fingerprints may be reduced from matte finish with rubbing alcohol. Do not use high heat to apply wrap, PPF or ceramic coating as the heat may damage the clear finish and/or the resin within the carbon fiber product. Do not drive your vehicle equipped with carbon fiber products through an automated or commercial car wash due to the high-water pressure, high water temperature and unknown soap content. Wash your vehicle by hand with low water pressure, low water temperature and a quality automotive grade Ph neutral soap formulated to minimize scratching and fading (intended for late model clear coat finishes). Do not use a high-pressure wand on carbon fiber surfaces.

Ford Factory Shop Manual purchase options [www.motorcraftservice.com](http://www.motorcraftservice.com)