



M-16612-MG,MM
2024+MY Mustang GT & Dark Horse
Carbon Fiber Hood Vent

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF
FORD PERFORMANCE PARTS © Ford Motor Company 2020

PRIOR TO INSTALLATION READ THESE INSTRUCTIONS COMPLETELY
For questions, Call the FORD PERFORMANCE Techline 1-800-367-3788

Please visit <https://www.performanceparts.ford.com> for warranty information



Ford Factory Shop Manual purchase options www.motorcraftservice.com


NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF
 FORD PERFORMANCE PARTS © Ford Motor Company 2020

BOM

Carbon Fiber Hood Vent	QTY 1
Nut & Washer W701567-S450B	QTY 4

REMOVAL

1. Remove the nuts and washers and the T-nuts. Save the T-nutss for installation. New nuts and washers are provided in the kit.
 1. Remove the nuts.
Torque: 44 lb.in (5 Nm)
2. Release the tabs and remove the hood scoop.



E405419


Ford Factory Shop Manual purchase options www.motorcraftservice.com

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF
FORD PERFORMANCE PARTS © Ford Motor Company 2020

INSTALATION

1. Temporarily tape the T-nuts in place on the carbon fiber hood vent.
2. Install the carbon hood vent by reversing the removal process.

NOTE: Do not over tighten threaded fasteners, composite components will not withstand high pressure and may crack or fail by such force.



Ford Factory Shop Manual purchase options www.motorcraftservice.com



M-16612-MG,MM
2024+MY Mustang GT & Dark Horse
Carbon Fiber Hood Vent

NO PART OF THIS DOCUMENT MAY BE REPRODUCED WITHOUT PRIOR AGREEMENT AND WRITTEN PERMISSION OF
FORD PERFORMANCE PARTS © Ford Motor Company 2020

Care Instructions

Carbon fiber products are durable, but still requires care and maintenance to stay looking good. More specifically, keep the products clean and minimize exposure to the sun. Gloss finish products should be waxed with a car care product designated for clear coat finishes (non-abrasive). Matte finish products should not be waxed, surface may become spotty. Grease or fingerprints may be reduced from matte finish with rubbing alcohol. Do not use high heat to apply wrap, PPF or ceramic coating as the heat may damage the clear finish and/or the resin within the carbon fiber product. Do not drive your vehicle equipped with carbon fiber products through an automated or commercial car wash due to the high-water pressure, high water temperature and unknown soap content. Wash your vehicle by hand with low water pressure, low water temperature and a quality automotive grade Ph neutral soap formulated to minimize scratching and fading (intended for late model clear coat finishes). Do not use a high-pressure wand on carbon fiber surfaces.

Ford Factory Shop Manual purchase options www.motorcraftservice.com